




8. Solder a wire across the 2 paths shown.



9. In the radio menu, set the path to "Internal".
10. Assemble the radio in the reverse order and test.