

Chatter Box!TM
THE ORIGINAL COMMUNICATOR

**Tandem
PRO2ⁱ**

RIDER TO PASSENGER WIRED INTERCOM



Owner's Manual

Chatter Box!TM

16918 Edwards Road, Cerritos, CA 90703
www.chatterboxusa.com
Customer Service: 888-452-2269
info@chatterboxusa.com

Congratulations on your purchase of the Chatterbox product.
For additional information, go to chatterboxusa.com

For product support, go to
www.chatterboxusa.com/support

Unpacking and inspection

Please check and make sure that you have everything listed below inside the box. If you find any parts missing or that have been damaged, please contact our customer service immediately.

1		Tandem Pro 2 Unit with factory installed rechargeable lithium Ion Battery
2		Helmet mounting bracket with Cradle, two screws
3		USB charging cable and AC adaptor


Battery

The Tandem Pro 2 comes with a rechargeable battery pre-installed inside of the unit. Please do not attempt to open the case to replace the battery. We recommend that the battery be pre-conditioned to restore to the original state.

- 1) *Discharge the battery completely by leaving the unit on until the battery is completely drained.*
 - 2) *Charge it completely using the charger supplied with the kit. It should take about 5 hours to fully charge the battery.*
- If you are planning to store the unit for a long period of time, store it after fully charging the battery. Upon using it again, please follow the pre-conditioning process described above. To reduce the risk of damage to the battery, do not use any other charger except the one supplied with the kit. Make sure the battery is always stored at room temperature.

Buttons and inputs

Please refer to the picture shown below to find out the location and functions of each button.



Buttons & Inputs	Description
1 Power Button (Intercom mode)	• Power on and off • Turn on the power button to enter the Intercom mode - Turn off the power button to terminate the Intercom mode
2 Volume Control	• Control speaker volume
3 DC Input	• Input power cord for charging

4 Student headset input	• Input for Student headset
5 Headset Input	• Input for headset

Accessories

1		Student Headset	5		Headsets extension cord
2		3.5mm to 6 pin plug converter	6		Helmet mounting bracket with Cradle, two screws
3		Headset including microphones for full face helmets	7		Charger (AC adaptor, USB cable)
4		Microphone for open face helmets	8		Sponge and Velcro Kit (5 pieces of microphone sponge, 5 pairs of speaker Velcro)

Chatterbox USA Limited Warranty

Chatterbox USA guarantees that each new product will be free from defective materials and workmanship for a period of one (1) year from the date of original purchase. Chatterbox will remedy any such defect by repair or replacement (at our discretion) of the products, provided they are delivered to the address listed below, intact for examination, with all transportation charges prepaid and accompanied by a copy of the original retail sales receipt. The provisions of this warranty shall not apply to any unit which has been subject to misuse, neglect, incorrect installation, unauthorized modification, accident, or has been repaired or altered outside of our factory. The express warranty contained herein is in lieu of all other warranties, expressed, implied or statutory, including without limitation any warranty of merchantability or fitness for a particular use. In no event will Chatterbox be liable to the buyer for any damages, including special, incidental, indirect, or consequential.

Technical Specification

Maximum speed of operation	120 km/h (70 miles/h)
Power supply pack	Poly-Li, 500 mAh rechargeable
Power supply pack	DC 3.7V, Li-ion rechargeable
Battery life for Intercom	10 hours talk time, 20 hours of stand by time
Battery charging time	5 hours for full charge
Operating temperature	-20C + 50C
Dimensions	40 (H) x 80 (W) x 10 (D) mm
Weight	1.3 oz. (with battery)