



X2 SLIM-P Quick Manual



- : Simultaneous Push
- : Push
- : Push Count
- : Push Time(or less)
- : Push Time(or more)

► Pairing Mode (power off mode Start)




► Power ON




► Power OFF



► Phone Call



► FM Radio Mode




Previous Channel Search




Next channel Search



Volume up




Volume Down




► Transceiver TX Mode




► Music Play Mode



► Intercom Change




► Communication Mode Function Change




Voice Calling On



Language Change



Key Lock On/Off



► Transceiver TX Mode



Remote Control

► PTT Dongle Pairing

PTT Pairing



If pairing fails within 10 seconds, restart from the beginning

